











PROFESSIONALS USE WALTHER STRONG

STEP 1



Apply RILICONE in an even bead

STEP 2



Spray RILICONE bead evenly with smoothing spray

STEP 3




Choose RILICONE finishing bead and run joint spatula down the silicone, pressing firmly

- 4 x joint spatulas made of flexible plastic
- Create a water-tight seal
- Ensures no germs are put into the silicone
- Creates a clean and consistent finished look
- 16 different bead finishes











Specifically designed to press the sealant into the joint to create a complete water-tight seal









