

Section 1 - Identification of The Material Manufacture

Company Details:

Walther Strong & Company Ltd
Unit 3, Dysart Road
Autumn Business Park
NG31 7DD

Phone: 01780 437222

Website: www.waltherstrong.com

Email: enquiries@waltherstrongandco.com

Section 2 - Application

Flat plasterboard joints must be reinforced with Walther Strong glass fibre mesh tape. Position the tape and spread the plaster along each joint. To minimise the risk of cracking, ensure that the plaster is pushed through the tape well into any gaps between the plasterboards. Apply plaster to the plasterboard surface and joints with firm pressure after the joint treatment has stiffened but not set. Build out to a 2mm thickness in two applications, wet-on-wet and trowel to a smooth matt finish. Sand each joint once it has dried, to achieve a smooth matt finish.

Section 3 - How to Cut

Use a knife or trowel to cut to size

Section 4 - Storage

Store between 8-30°C. Do not use if left in a van overnight in cold weather. Remove, bring to room temperature (minimum 15°C) before using if cold weather. Avoid frost.

		Metric	Imperial	ASTM Method
Construction: (per 100mm)	Warp Weft	36 36	9 9	D-3375
Weight: (g/m² - oz/yd²)		63.1+/-2.2	1.85+/-0.1	D-3776
DPU (Coating and PSA on fabric in Weight %)		40-45%	40-45%	SGTF
Thickness: (per mm - per inch)		0.3	0.01	D-1777
Tensile Strength: (N/2.54cm - lbs/in)	Warp Weft	228 470	50 105	



PRODUCT CODE	PRODUCT DESCRIPTION	BOX QTY
TP-ORNSCRIM50X90PR	50MM X 90M	36
TP-ORNSCRIM75X90PR	75MM X 90M	24
TP-ORNSCRIM100X90PR	100MM X 90M	18
TW-TP-SCRIMORN50X90PR	TWIN PACK 50MM X 90M	18