

# SLEEPER TAPE APPLICATION

## Step 1 - Bottom sleeper (first sleeper at the base):

- Place the tape on the exterior face, leaving 50mm along the base.
- Fold the tape under the sleeper along the bottom edge.
- Bring the tape up the interior face so the inside is protected too.

## Step 2 - Subsequent sleepers:

1. Line up the tape with the top edge of the interior face.
2. Run it down the interior face.
3. Overlap the tape from the sleeper below by 50mm to prevent water getting in.

## Step 3 - Tips for a neat and effective job:

1. Keep the tape smooth and tight, no gaps or wrinkles.
2. Always maintain the 50mm overlap.
3. Work from bottom to top, so water sheds correctly.



Position the bottom sleeper, which rests directly on the ground, with tape along the bottom and on the interior face of the sleeper bed. All subsequent sleepers should overlap by 50 mm to ensure moisture cannot seep through.