

# WALTHER STRONG®

# H2O LIQUID MASK

## 250ML, 1L & 5L



# 2-IN-1 PRIME & MASK

FAST, CLEAN, PROFESSIONAL RESULTS EVERY TIME



TIME SAVING



CLEAN REMOVAL



EASY TO APPLY

## YOUR NEAREST MERCHANT:

# WALTHER STRONG®



## STEP 1- PREPARE SURFACE

Prepare Surface - remove all debris & dust and sand down timber. If the timber had been previously painted ensure the timber is fully sanded before applying H20.



## STEP 2 - APPLY H20 PRIME & MASK

Apply H20 Prime & Mask - stir thoroughly then apply H20 with either a synthetic bristle brush, long nap roller (mid pile) or conventional airless sprayer, recommended typical fluid tip size of 0.013 to 0.017. Theoretical coverage 2m squared /Litre at 200µm DFT.



## STEP 3 - LET FULLY CURE

Leave to Fully Cure - once H20 prime & mask turns clear (fully cured) - repeat process for a second coat This should take 30-60 minutes.



## STEP 4 - CUT AROUND & PEEL OFF

Cut & Peel - carefully cut around the inside edge of frames with a sharp knife & simply peel the mask away from glass. After use, clean applicators with water.

**CAN BE SPRAYED, ROLLED OR BRUSH APPLIED**



**AVAILABLE IN**

**250ML [ H20-PRIME-250ML ]**

**1L [ H20-PRIME-1LTR ]**

**5L [ H20-PRIME-5LTR ]**

*DO NOT use on etched, frosted, stained, or leadlight glass, or on plastic or PVC surfaces. Always test on intended surface/substrate before use.*

**YOUR NEAREST MERCHANT:**